

GREEN MAINTENANCE GUIDE FOR LSI VINYL TILE



Initial Maintenance (No floor finish)

1. Sweep and/or dust mop the floor to remove all dirt or grit
2. Thoroughly clean the floor using Stride Citrus Cleaner at recommended dilution rate. Use blue or green pad
3. Pick up cleaner solution with wet vac or auto scrubber
4. Rinse floor thoroughly and allow it to dry

If no finish is desired skip to Daily Maintenance.

Initial Maintenance (Using floor finish)

1. Sweep and/or dust mop the floor to remove all dirt or grit
2. Apply Freedom SC according to label directions with a mop and bucket/wringer, and allow it to set for 5 minutes. Do not let it dry on the floor.
3. Scrub with blue or green pads
4. Pick up cleaning solution with wet vac or auto scrubber
5. Rinse floor thoroughly and allow it to dry

Apply Floor Finish

1. Post "Wet Floor" signs
2. After the floor has been cleaned, rinsed and allowed to dry apply three (3) medium (2,000 sq.ft. per gallon) coats of Aquaria Floor Finish to the floor
Note: Aquaria Floor Finish, Stride Neutral Cleaner and Freedom SC Stripped are Green Seal Certified products and are recommended for use in an eco-friendly program.
3. Apply no more than four (4) coats of Aquaria in a 24-hour period. Additional 2-3 coats may be applied on the floor the following day after thoroughly cleaning the floor
4. Allow 10-15 minutes after polish is dry to the touch before applying additional coat (usually 45-60 minutes are required between coats)

Daily Maintenance (Finish or no finish)

1. Sweep and/or dust mop the floor daily to remove surface dirt
2. Post "Wet Floor" signs
3. Damp mop or auto scrub floor using Stride Neutral Cleaner according to label instructions. Use red pad for daily maintenance

Buffing using 300-rpm cord electric (Only for floors using finish)

1. Sweep and/or dust mop the floor to remove all dirt or grit
2. Damp mop or auto scrub using Stride Citrus Cleaner with a 3M red pad according to label instructions
3. When dry use a 3M white pad for dry buffing

Recoat Procedure

1. Sweep and/or dust mop the floor to remove all dirt or grit
2. Post "Wet Floor" signs
3. Thoroughly clean using Stride Citrus Cleaner according to label directions and a blue or green scrubbing pad. This can be done with a 175-rpm swing machine or auto scrubber
4. Rinse floor well and allow to dry
5. Recoat with two (2) coats of Aquaria Floor Finish

Stripping Procedure

1. Sweep and/or dust mop the floor to remove all dirt or grit
2. Use Freedom SC through an RTD dilution control device
3. Apply to floor with a mop and bucket/wringer
4. Let soak for 5-7 minutes, keeping uniformly wet but do not over-wet the floor
5. Scrub with green or blue pad
6. Pick up with wet vac or auto scrubber
7. Rinse floor well
8. Allow to dry
9. Apply four (4) coats of Aquaria Floor Finish. Apply no more than four (4) coats in a 24-hour period. Allow 10-15 minutes after the finish is dry to the touch before applying the next coat. Additional 2 to 4 coats of finish may be applied the following day if desired after cleaning floor thoroughly

CAUTION!!!

- Always clean floor before buffing. Do not buff a dirty floor
- Turn pad often to prevent build up
- Buffing is recommended on coated floors only
- Do not buff in one place too long as burn marks may occur

For technical support in Canada call Wood Wyant at 1.800.361.7691

For technical support from LSI Floors call 1.800.449-3916